



**Air Lift  
Performance  
ALP3  
Part No. 27711  
Stance Guard**



For maximum effectiveness and safety, please read these instructions completely before proceeding with installation.

*Failure to read these instructions can result in an incorrect installation.*

MN-1136 • (032108) • ERN 8249

**AIR LIFT**  
**PERFORMANCE**®

**INSTALLATION GUIDE**

# Introduction

The purpose of this publication is to assist with the installation, maintenance of the Air Lift Performance ALP3 Stance Guard kit.

Read and understand the entire installation guide before beginning installation or performing any maintenance, service or repair. The information includes step-by-step installation information and functionality.

Air Lift Company reserves the right to make changes and improvements to its products and publications at any time. For the latest version of this manual, contact Air Lift Performance at (800) 248-0892 or visit [airliftperformance.com](http://airliftperformance.com).

## NOTATION EXPLANATION

Hazard notations appear in various locations in this publication. Information which is highlighted by one of these notations must be observed to help minimize risk of personal injury or possible improper installation which may render the vehicle unsafe. Notes are used to help emphasize areas of procedural importance and provide helpful suggestions. The following definitions explain the use of these notations as they appear throughout this guide.



**DANGER**

INDICATES IMMEDIATE HAZARDS WHICH WILL RESULT IN SEVERE PERSONAL INJURY OR DEATH.



**WARNING**

INDICATES HAZARDS OR UNSAFE PRACTICES WHICH COULD RESULT IN SEVERE PERSONAL INJURY OR DEATH.



**CAUTION**

INDICATES HAZARDS OR UNSAFE PRACTICES WHICH COULD RESULT IN DAMAGE TO THE MACHINE OR MINOR PERSONAL INJURY.

---

**NOTE** *Indicates a procedure, practice or hint which is important to highlight.*

---

## Limited Warranty and Return Policy


Air Lift Company provides a Limited Warranty to the original purchaser of its Air Lift Performance products, subject to the requirements and exclusions set forth in the full Limited Warranty and Return Policy that is available online at [www.airliftperformance.com/warranty](http://www.airliftperformance.com/warranty).

For additional warranty information contact Air Lift Company customer service.

# Install Stance Guard

**NOTE** *An alternative mounting method to the instructions below, is to secure the dongle using the supplied zip-ties to a stable component or wiring harness behind the dash. Zip-ties may also be used to secure both ends of the cable to prevent it from coming loose.*

1. Separate the two sides of velcro from one another. Remove the liner from one of the pieces of velcro and apply it to the bottom (side with screws) of the dongle assembly. Retain the other side of velcro for later use.
2. Locate where the display USB-Micro cable interfaces with the harness USB-connector and disconnect this interface.



3. Determine where to mount the dongle. It must be placed somewhere that is not fully encapsulated so that the audible buzzer can be heard. This can be in an open compartment behind the dash. Ensure both cable connections can reach this location.
4. Remove the liner from the second velcro piece and attach to the stable mounting surface you have selected.
5. Connect the dongle to the USB Micro cable and the USB-connector and then attach the dongle to the other piece of velcro behind the dash.

## Stance Guard Functionality

When enabled, Stance Guard

1. Prevents users from making pressure changes while the vehicle is moving.
2. Alerts the user through an audible alarm when their pressure change is out of their set minimum or maximum pressure range.

See user guide MN-948 for further details on how to enable this feature.



## Need Help?

Contact our customer service department by calling  
(800) 248-0892, Monday through Friday.  
If outside the USA or Canada, call (517) 322-2144.



*Thank you for purchasing Air Lift Performance products!*



Air Lift Company • 2727 Snow Road • Lansing, MI 48917 or PO Box 80167 • Lansing, MI 48908-0167  
Toll Free (800) 248-0892 • Local (517) 322-2144 • Fax (517) 322-0240 • [www.airliftperformance.com](http://www.airliftperformance.com)

Printed in the USA  
JJC-0821

California: ⚠️WARNING: Cancer and Reproductive Harm - [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)